

The Thermostats You Rely On Just Got Better!



NEW tekmar Radiant Thermostat 519

Replaces tekmar Thermostat 509



Includes Slab Sensor 079

What's New?

Easier to Wire

 Connect wires to a wall mounted base instead of the back of the thermostat

Easier to Use

- Simple up / down triangle shaped buttons make these thermostats completely user friendly
- The 'Heat On' indicator provides operational status

Easier to View

 A bright white backlight & large numbers make it easy to read the display in all lighting conditions

Auxiliary Sensor Options

- Floor temperature control with floor minimum & maximum settings
- Dual temperature display of outdoor, floor or remote temperature depending on auxiliary sensor selection

Simple Installer Access

- No need to open the thermostat to access DIP switches
- Limit homeowner access to installer settings

What's the Same?

Just like the previous models, the 518 & 519 are designed to maximize comfort in radiant heating systems by providing warm floors while reducing temperature swings.













Snow Melting





Alternative Energy

Zoning

Setpoint







Compare Classic Thermostats

Discontinued Models

New Models











				/	
Features	507*	508*	509*	518	519
Air Temperature Control	•	•	•	•	•
Floor Temperature Control	-	•	•	•	•
Packaged with Slab Sensor 079	-	-	•	-	•
One Auxiliary Sensor Input	-	•	•	•	•
Number of Buttons	4	4	4	2	2
Dual Temperature Display	-	-	-	•	•
White Backlight	-	-	-	•	•
Wire to Thermostat Base	-	-	-	•	•
Wire to Back of Thermostat	•	•	•	-	-

^{*}Thermostats 507, 508 and 509 will be discontinued as of June 01, 2013

Front (518 & 519)

Thermostat Base (518 & 519)

Optional Adapter Plate 012

Auxiliary Sensor Options









Outdoor Sensor 070



Slab Sensor 079



Indoor Sensor 084